Installation Center

GARMIN GNS 430 VHF Communications Transceiver/VOR/ILS Receiver / GPS Receiver

Repair Station:

CB3R417L

Name:

Instrument Overhaul Service

Address:

1981 N. Marshall Ave

El Cajon, CA 92020

FAA APPROVED FLIGHT MANUAL SUPPLEMENT GARMIN GNS 430 VHF COMMUNICATION TRANSCEIVER/ **VOR/ILS RECEIVER / GPS RECEIVER**

AIRCRAFT MAKE: GRUMMAN AMERICAN

AIRCRAFT MODEL: AIRCRAFT SERIAL NO:

AA5B AA5B1145

This document must be carried in the aircraft at all times. It describes the operating procedures for The GARMIN GNS 430 navigation system when it has been installed in accordance with GARMIN Installation Manual 190-00140-02 REV R and FAA Form 337. Dated ______///\documents

For aircraft with an FAA Approved Airplane Flight Manual, this document serves as the FAA Approved Flight Manual Supplement for the GARMIN GNS 430. For aircraft that do not have an Approved flight manual, this document serves as the FAA Approved Supplemental Flight Manual For the GARMIN GNS 430.

The information contained herein supplements or supersedes the basic Airplane Flight Manual only in those areas listed herein. For limitations, procedures, and performance information not contained in this document, consult the basic Airplane Flight Manual.

FAA APPROVED Jupils Jo DATE: JAN 11 2010

Page 1 of 8

Aircraft Make: GRUMMAN AMERICAN Aircraft Model: AA5B

Aircraft Serial Number: AA5B1145

GARMIN GNS 430 VHF Communications Transceiver / VOR/ILS receiver / GPS Receiver

Table of Contents

SECTIONPAGE	
GENERAL3	
LIMITATIONS4	
EMERGENCY PROCEDURES5	
NORMAL PROCEDURES6	
PERFORMANCE8	
WEIGHT AND BALANCE8	
AIRPLANE & SYSTEM DESCRIPTION	

Aircraft Model: AA5B

Aircraft Serial Number: AA5B1145

GARMIN GNS 430 VHF Communications Transceiver / VOR/ILS Receiver / GPS Receiver

SECTION I GENERAL

- 1. The GNS 430 System is a fully integrated, panel mounted instrument, which contains a VHF Communications Transceiver, a VOR/ILS receiver, and a Global Positioning System (GPS Navigation computer. The system consist of a GPS antenna, GPS Receiver, VHF VOR/LOC/GS antenna, VOR/ILS receiver, VHF COMM antenna and VHF Communications Transceiver. The primary function of the VHF Communication portion of the equipment is to Facilitate communication with Air Traffic Control. The primary function of the VOR/ILS Receiver portion of the equipment is to receive and demodulate VOR, Localizer, and Glide Slope signals. The primary function of the GPS portion of the system is to acquire signals from the GPS system satellites, recover orbital data, make range and Doppler measurements, And process this information in real-time to obtain the user's position, velocity, and time.
- 2 Provided the **GARMIN GNS 430's** GPS receiver is receiving adequate usable signals, it has been demonstrated capable of and has been shown to meet the accuracy specifications for:
 - VFR/IFR enroute, terminal, and non-precision instrument approach (GPS, Loran, C, VOR, VOR-DME, TACAN, NDB, NDB-DME, RNAV) operation within the U.S. National Airspace System in accordance with AC 20-138.
 - One of the approved sensors, for a single or dual GNS 430 installation, for North Atlantic Minimum Navigation Performance Specification (MNPS) Airspace in accordance with AC 91-49 and AC 120-33.
 - The systems meets RNP5 airspace (BRNAV) requirements of AC 90-96 and in accordance with AC 20-138, and JAA AMJ 20X2 Leaflet 2 Revision 1, provided it is receiving usable navigation information from the GPS Receiver.

Navigation is accomplished using the WGS-84 (NAD-83) coordinate reference datum. Navigation date is based upon use of only the Global Positioning System (GPS) operated by the United States of America.

Aircraft Model: AA5B

Aircraft Serial Number: AA5B1145

GARMIN GNS 430 VHF Communications Transceiver / VOR/ILS Receiver / GPS Receiver

SECTION II LIMITATIONS

1. The **GARMIN GNS 430** Pilot's Guide, P/N 190-00140-00, Rev. A, dated October, 1998, or later appropriate revision, must be immediately available to the flight crew whenever navigation is predicated on the use of the system.

The **GARMIN 400** Series Pilot's Guide Addendum, Display Interface for Traffic Weather Data, must be immediately available to the flight crew if the BFGoodrich WX-500 Stormscope or the BFGoodrich SKYWATCH Traffic Advisory System (TAS) is installed.

2. The GNS 430 must utilize the following or later FAA approved software versions:

Sub-System	Software Version
Main	2.00
GPS	2.00
COMM	1.22
VOR/LOC	1.25
G/S	2.00

The Main Software version is displayed on the GNS 430 self test page immediately after turn on for 5 seconds. The remaining system software version can be verified group subpage 2, "SOFTWARE/DATEBASE VER".

- 3 IFR enroute and terminal navigation predicated upon the GNS 430's GPS Receiver is prohibited unless the pilot verifies the currency of the data base or verifies each selected waypoint for accuracy by reference to current approved data.
- 4. Instrument approach navigation predicated upon the GNS 430's GPS Receiver must be accomplished in accordance with approved instrument approach procedures that are retrieved from the GPS equipment data base. The GPS equipment database must incorporate the current update cycle.
 - (a) Instrument approaches utilizing the GPS receiver must be conducted in the approach mode and Receiver Autonomous Integrity Monitoring (RAIM) must be available at the Final Approach Fix.
 - (b) Accomplishment of ILS, LOC, LOC-BC, LDA, SDF, MLS or any other type of approach not approved for GPS overlay with the GNS 430's GPS receiver is not authorized.

Aircraft Model: AA5B

GARMIN GNS 430 VHF Communications Transceiver / VOR/ILS Receiver / GPS Receiver

Aircraft Serial Number: AA5B1145

- © Use of the GNS 430 VOR/ILS receiver to fly approaches not approved for GPS require VOR/ILS navigation data to be present on the external indicator.
- (d) When an alternate airport is required by the applicable operating rules, it must be served by an approach based on other than GPS or Loran-C navigation, the aircraft must have the operational equipment capable of using that navigation aid, and the required navigation aid must be operational.
- (e) VNAV information may be utilized for advisory information only, Use of VNAV information for Instrument Approach Procedures does not guarantee Step-Down Fix altitude protection, or arrival at approach minimums in normal position to land.
- 5. If not previously defined, the following default settings must be made in the "SETUP 1" menu of the GNS 430 prior to operation (refer to Pilot's Guide for procedure if nec):
 - (a) dis, spd.....nm (sets navigation units to "nautical miles" and "knots")
 - (b) alt, vs ft fpm (sets altitude units to "feet" and "feet per minute")
 - © map datum... WGS 84 (sets map datum to WGS-84, see note below)
 - (d) posn.....deg-min (sets navigation grid units to decimal minutes)

Note: In some areas outside the United States, datums other than WGS-84 or NAD-83 may be used. If the GNS 430 authorized for use by the appropriate Airworthiness Authority, the required geodetic datum must be set in the GNS 430 prior to its use for navigation.

SECTION III EMERGENCY PROCEDURES

ABNORMAL PROCEDURES

- 1. If **GARMIN GNS 430** navigation information is not available or invalid, utilize remaining operational navigation equipment as required.
- If "RAIM POSITION WARNING" message is displayed the system will flag and no longer provide GPS based navigational guidance. The crew should revert to the GNS 430 VOR/ILS Receiver or an alternate means of navigation other than the GNS 430's GPS Receiver.
- 2. If "RAIM IS NOT AVAILABLE" message is displayed in the enroute, terminal, or initial approach phase of flight, continue to navigate using the GPS equipment or revert to an

Aircraft Make:

GRUMMAN AMERICAN

Aircraft Model: AA5B

AA5B

GARMIN NGS 430 VHF Communications Transceiver / VOR/ILS Receiver / GPS Receiver

Aircraft Serial Number: AA5B1145

Alternate means of navigation other than the GNS 430's GPS receiver appropriate to the route and phase of flight. When continuing to use GPS navigation, position must be verified every 15 minutes using the GNS 430's VOR/ILS receiver or another IFR-approved navigation system.

- 4. If "RAIM IS NOT AVAILABLE" message is displayed while on the final approach segment, GPS based navigation will continue for up to 5 minutes with approach CDI sensitivity (0.3 nutical mile). After 5 minutes the system will flag and no longer provide course guidance wth approach sensitivity. Missed approach course guidance may still be available with 1 nautical mile CDI sensitivity by executing the missed approach.
- 5. In an in-flight emergency, depressing and holding the Comm transfer button for 2 seconds will select the emergency frequency of 121.500 Mhz into the "Active" frequency window.

SECTION IV NORMAL PROCEDURES

1. DETAILED PROCEDURES

Normal operating procedures are described in the GARMIN GNS 430 Pilot's Guide, P/N 190-00140-00, Rev. A, dated October 1998, or later appropriate revision.

2. PILOT'S DISPLAY

The GNS 430 System data will appear on the Pilot's CDI. The source of data is either GPS or VLOC as annunciated on the display above the CDI key.

Note: Its is the pilot's responsibility to assure that published or assigned procedures are correctly complied with. Course guidance is not provided for all possible ARINC 424 Leg types. See the GNS 430 Pilot's Guide for detailed operating procedures regarding Navigation capabilities for specific ARINC 424 leg types.

3. AUTOPILOT / FLIGHT DIRECTOR OPERATION

Coupling of the GNS 430 System steering information to the autopilot can be accomplished by engaging the autopilot in the NAV or APR mode.

When the autopilot system is using course information supplied by the GNS 430 System and the course pointer is not automatically driven to the desired track, the course pointer on the HIS must be manually set to the desired track (DTK) indicated by the GNS 430.

Aircraft Model: AA5B

GARMIN GNS 430 VHF Communications Transceiver / VOR/ILS Receiver / GPS Receiver

Aircraft Serial Number: AA5B1145

For detailed autopilot operational instructions, refer to the FAA Approved Flight Manual Supplement for the autopilot.

4. CROSSFILL OPERATIONS

For dual GNC 400 Product Series installations, crossfill capabilities exist between the number one and number two GNC 400 Systems. Refer to the GARMIN GNS 430 Pilot's Guide for detailed crossfill operating instructions.

5. AUTOMATIC LOCALIZER COURSE CAPTURE

By default, the GNS 430 automatic localizer course capture feature is enabled. This feature provides a method for system navigation data present on the external indicators to be switched automatically from GPS guidance to localizer / glide slope guidance as the aircraft approaches the localizer course inbound to the final approach fix. If an offset from the final approach course is being flown, it is possible that the automatic switch from GPS course guidance to localizer / glide slope course guidance will not occur. It is the pilot's responsibility to ensure correct system navigation data is present on the external indicator before continuing a localizer based approach beyond the final approach fix. Refer to the GNS 430 Pilot's Guide for detailed operating instructions.

6. DISLAY OF LIGHTING STRIKE DATA

For installations that interface the BFGoodrich WX-500 Stormscope and the GNS 430, Lighting strike data detected by the WX-500 will appear on the GNS 430. For detailed Operating instructions regarding the interface of the GNS 430 with the WX-500, refer to the WX-500 Pilot's Guide and the GNS 430 Pilot's Guide Addendum for the WX-500 Stormscope interface.

7. DISPLAY OF TRAFFIC ADVISORY DATA

For installation that the interface the BFGoodrich SKYWATCH traffic Advisory System (TAS) and the GNS 430, traffic data detected by the SKYWATCH will appear on the GNS 430. For detailed operating instructions regarding the interface of the GNS 430 with the SKYWATCH, refer to the FAA Approved Flight Manual Supplement for the SKYWATCH, the Pilot's guide for the SKYWATCH and the GNS 430 Pilot's Guide Addendum for the SKYWATCH traffic Advisory System interface.

Aircraft Model: AA5B

Aircraft Serial Number: AA5B1145

GARMIN GNS 430 VHF Communications Transceiver / VOR/ILS Receiver / GPS Receiver

SECTION V PERFORMANCE

No Change

SECTION VI WEIGHT AND BALANCE

See current weight and balance data.

SECTION VII AIRPLANE & SYSTEM DESCRIPTIONS

See GNS 430 Pilot's Guide for a complete description of the GNS 430 system.